

Liste des terminaux compatibles

Navigateur

Navigateur Android
Navigateur Fennec
navigateur IEMobile
Navigateur MAUI
Navigateur Minimo
Navigateur NetFront/3.5
navigateur Opera
navigateur Opera Mini
navigateur Opera Mobi
Navigateur Origyn
Navigateur R-T Mobile
navigateur Safari Mobile
Navigateur Teleca-Obigo
Navigateur WinWAP
navigateur WM5 Iris

Modèle	Marque
beTouch E101	Acer
beTouch E200	Acer
E100	Acer
Glofish DX900	Acer
Liquid	Acer
M900	Acer
S200	Acer
X960	Acer
T480	Airis
AIR99	Airness
MK99	Airness
SLIDE99	Airness
XS99	Airness
	303 Alcatel
531 one touch	Alcatel
BF4	Alcatel
BG3	Alcatel
BG3-color	Alcatel
BH4	Alcatel
Crystal	Alcatel
CTH3	Alcatel
ELLE-N1	Alcatel
ELLE-N3	Alcatel
GLAMPHONE-ELLE	Alcatel
M5	Alcatel
Mandarina Duck Moon	Alcatel
Miss Sixty	Alcatel
OH1C	Alcatel
OH2	Alcatel
OH5	Alcatel
One Touch 280	Alcatel
One Touch 303	Alcatel

One Touch 303A	Alcatel
One Touch 305	Alcatel
One Touch 363	Alcatel
One Touch 383	Alcatel
One Touch 505	Alcatel
One Touch 600	Alcatel
One Touch 660	Alcatel
One Touch 708	Alcatel
One Touch 800	Alcatel
One Touch 802Y	Alcatel
One Touch 808	Alcatel
One Touch C552	Alcatel
One Touch C700	Alcatel
One Touch C717	Alcatel
One Touch C750	Alcatel
One Touch S320	Alcatel
One Touch S621	Alcatel
One Touch V570	Alcatel
One Touch V670	Alcatel
OT-216	Alcatel
OT-880	Alcatel
OT-C550	Alcatel
OT-C551	Alcatel
OT-C630	Alcatel
OT-C701	Alcatel
OT-C707	Alcatel
OT-C820	Alcatel
OT-C825	Alcatel
OT-I650	Alcatel
OT-S319	Alcatel
OT-S319A	Alcatel
OT-S520	Alcatel
OT-S853	Alcatel
OT-S920	Alcatel
OT-v770	Alcatel
TH3	Alcatel
TH4	Alcatel
Vodafone 541	Alcatel
Vodafone-330-FM	Alcatel
Vodafone-331	Alcatel
Vodafone-331-FM	Alcatel
	8512 Amoi
	8709 Amoi
	9109 Amoi
A500	Amoi
Chicago	Amoi
D80	Amoi
D89	Amoi
E610	Amoi
E78	Amoi
F8	Amoi
H9	Amoi

New York	Amoi
VDA GPS	Amoi
iPad	Apple
iPhone	Apple
iPod	Apple
	5 Archos
5 IT	Archos
A605	Archos
Galaxy Mini	Asus
GalaxyII	Asus
GalaxyMini2	Asus
M930	Asus
Nuvifone A50	Asus
Nuvifone-M20	ASUS
P505	Asus
P525	Asus
P527	Asus
P550/	Asus
P565	Asus
P735	Asus
P750	Asus
Pegasus	Asus
Vodafone 1520	Asus
CDM8615	Audiovox
NEO200	Bellwave
E55	BenQ
E61	BenQ
E72	BenQ
E81	BenQ
EF51	BenQ
EF61	BenQ
EF71	BenQ
M300	BenQ
M315	BenQ
M700V05	BenQ
MD-300H	BenQ
NIKE1	BenQ
P51	BenQ
S700	BenQ
S82	BenQ
S88	BenQ
SL91	BenQ
T60	BenQ
D615	Bird
K298	Bird
S305A	Bird
S689	Bird
S701	Bird
S710	Bird
S918	Bird
SC24	Bird
V600	Bird

V750	Bird
	6230 BlackBerry
	6280 BlackBerry
	7100 BlackBerry
	7130 BlackBerry
	7230 BlackBerry
	7250 BlackBerry
	7280 BlackBerry
	7290 BlackBerry
	7730 BlackBerry
	8230 BlackBerry
8350i	BlackBerry
	8530 BlackBerry
	8700 BlackBerry
8703e	BlackBerry
	8707 BlackBerry
	8800 BlackBerry
	8820 BlackBerry
	8830 BlackBerry
	8910 BlackBerry
	9100 BlackBerry
	9630 BlackBerry
	9650 BlackBerry
Bold 9000	BlackBerry
Bold 9700	BlackBerry
Curve 8300	BlackBerry
Curve 8310	BlackBerry
Curve 8320	BlackBerry
Curve 8330	BlackBerry
Curve 8520	BlackBerry
Curve 8900	BlackBerry
Pearl 8100	BlackBerry
Pearl 8110	BlackBerry
Pearl 8120	BlackBerry
Pearl 8130	BlackBerry
Pearl Flip 8220	BlackBerry
Storm 9500	BlackBerry
Storm 9530	BlackBerry
Storm2 9520	BlackBerry
Storm2 9550	BlackBerry
830CA	Casio
930CA	Casio
A1000	CECT
U600	CECT
Q808	Cosun
A100	Cricket
A200	Cricket
A300	Cricket
M1000	Cricket
TXT8026	Cricket
UTSTARCOM-CDM7126	Cricket
Mini 5	Dell

C888	EDL
Nucleus(C888)	EDL
EMobile-MM60	Emblaze
Enzo	Emgeton
DS180	Fly
E300	Fly
LX500	Fly
MC100	Fly
MX330	Fly
SL500i	Fly
SX210	Fly
SX300	Fly
SX305	Fly
V100	Fly
Chicago	Foxconn
DH910	Foxconn
Chrome	GHT
Piano	GHT
g-smart	Gigabyte
G-Smart t600	Gigabyte
GSmart-S1200	Gigabyte
MS800	Gigabyte
L10	Gionee
DX900	Glofiish
F900	Glofiish
V900	Glofiish
X500	Glofiish
X500+	Glofiish
X600	Glofiish
X610	Glofiish
X650	Glofiish
X900	Glofiish
G500i	Grundig
G500iS	Grundig
GR980	Grundig
1200P	Haier
G3	Haier
T10C	Haier
V200	Haier
G769	Hisense
H8800	Holleycomm
M100	Hosin
510 Voice Messenger	HP
HiPAQ6900	HP
Hound	HP
hw6500	HP
iPAQ	HP
iPAQ 110	HP
iPAQ 210	HP
iPAQ h6300	HP
IPAQ h6340	HP
iPAQ rw6800	HP

iPAQ rw6828	HP
iPAQ610	HP
iPAQ910	HP
iPAQrw6815	HP
KB1	HP
	3100 HTC
	8100 HTC
Advantage	HTC
Apache	HTC
Artist	HTC
Blue Angel	HTC
Bravo	HTC
Breeze	HTC
Charmer	HTC
CommanderC	HTC
Desire	HTC
Dopod 818	HTC
dopod C730	HTC
Dopod P660	HTC
Dopod P800W	HTC
dopod T8588	HTC
Dream	HTC
Espresso	HTC
Gemini	HTC
HD2	HTC
Hero	HTC
Juno	HTC
Legend	HTC
Leo	HTC
Magic	HTC
Mail	HTC
Maple	HTC
MAX 4G	HTC
MDA Compact	HTC
MDA-III	HTC
Neon	HTC
Nexus One	HTC
P3300	HTC
P3350	HTC
P3400	HTC
P3470	HTC
P3600	HTC
P4350	HTC
P6300	HTC
P6500	HTC
Prophet	HTC
Qtek 2020	HTC
Qtek 2020i	HTC
Qtek 8010	HTC
S100	HTC
S310	HTC
S620	HTC

S630	HTC
S710	HTC
S730	HTC
S740	HTC
Sapphire	HTC
SDA II Music	HTC
SDA Music	HTC
Shadow II	HTC
Smart	HTC
Snap	HTC
Snap S523	HTC
SPV C550	HTC
Star Trek	HTC
Tatoo	HTC
Tattoo	HTC
Titan	HTC
Tornado	HTC
Touch	HTC
Touch 3G	HTC
Touch Cruise	HTC
Touch Cruise 2009	HTC
Touch Diamond	HTC
Touch Diamond II	HTC
Touch Diamond2	HTC
Touch Dual	HTC
Touch HD	HTC
Touch II	HTC
Touch Pro	HTC
Touch Pro2	HTC
Touch Viva	HTC
Touch2	HTC
TyTN	HTC
TyTN II	HTC
Universal	HTC
Vodafone V3550	HTC
VPA Touch	HTC
Wizard	HTC
Xda IQ	HTC
C5005	Huawei
C5320	Huawei
C5330	Huawei
C5588	Huawei
C5589	Huawei
C7100	Huawei
C7500	Huawei
M318	Huawei
M328	Huawei
M750	Huawei
MD-TOUCH	Huawei
Pulse	Huawei
T520	Huawei
T566	Huawei

T7200	Huawei
U120	Huawei
U1211	Huawei
U1250	Huawei
U1270	Huawei
U1300	Huawei
U1310	Huawei
U1315	Huawei
U3205	Huawei
u3300	Huawei
U3305	Huawei
U3310	Huawei
U526	Huawei
U528	Huawei
U535	Huawei
U550	Huawei
U5700	Huawei
U5705	Huawei
U7200	Huawei
U7510	Huawei
U7517	Huawei
U7519	Huawei
U8230	Huawei
U9100	Huawei
V720	Huawei
Vodafone 332	Huawei
Vodafone 715	Huawei
Vodafone 716	Huawei
Vodafone 725	Huawei
Vodafone 735	Huawei
Vodafone 736	Huawei
Vodafone 810	Huawei
Vodafone 830	Huawei
VODAFONE 830i	Huawei
Vodafone 840	Huawei
Vodafone710	Huawei
A200	Hyundai
	6150 i-mate
	8502 i-mate
	9502 i-mate
JAQ	i-mate
PDAL	i-mate
Pebble	i-mate
Puma T	i-mate
SPL	i-mate
	520 i-mobile
	533 i-mobile
	650 i-mobile
INNO55	Innostream
B1-200H	INQ Mobile
INQ1	INQ Mobile
Q1-200H	INQ Mobile

CT-25	IXI
OGO-CT1X	IXI
B2010	K-Touch
B832	K-Touch
B858	K-Touch
D702	K-Touch
DT200	K-Touch
H888	K-Touch
V908	K-Touch
N120	KC Mobile
QS100	KC Mobile
CA33	KDDI
CA34	KDDI
CA35	KDDI
CA37	KDDI
CA38	KDDI
CA39	KDDI
CA3A	KDDI
CA3B	KDDI
CA3C	KDDI
CA3F	KDDI
CA3G	KDDI
HI34	KDDI
HI36	KDDI
HI38	KDDI
HI3A	KDDI
HI3B	KDDI
HI3C	KDDI
HI3D	KDDI
HI3E	KDDI
HI3F	KDDI
HI3G	KDDI
KC31	KDDI
KC35	KDDI
KC38	KDDI
KC39	KDDI
KC3B	KDDI
KC3D	KDDI
KC3I	KDDI
KC3N	KDDI
KC3O	KDDI
KC3Q	KDDI
MA31	KDDI
MA32	KDDI
MA33	KDDI
MA34	KDDI
Media SKIN	KDDI
PT33	KDDI
SA31	KDDI
SA34	KDDI
SA35	KDDI
SA3A	KDDI

SA3B	KDDI
SA3D	KDDI
SA3E	KDDI
SH31	KDDI
SH32	KDDI
SH33	KDDI
SH34	KDDI
SH35	KDDI
SH36	KDDI
SH37	KDDI
SH38	KDDI
SH3B	KDDI
SH3C	KDDI
SH3D	KDDI
SH3F	KDDI
SN29	KDDI
SN36	KDDI
SN37	KDDI
SN38	KDDI
SN39	KDDI
SN3A	KDDI
SN3B	KDDI
SN3C	KDDI
SN3D	KDDI
SN3E	KDDI
SN3F	KDDI
SN3G	KDDI
SN3H	KDDI
SN3I	KDDI
SN3J	KDDI
SN3K	KDDI
SN3L	KDDI
SN3M	KDDI
SN3N	KDDI
ST31	KDDI
ST32	KDDI
ST33	KDDI
ST34	KDDI
TS25	KDDI
TS34	KDDI
TS37	KDDI
TS38	KDDI
TS3A	KDDI
TS3B	KDDI
TS3C	KDDI
TS3D	KDDI
TS3E	KDDI
TS3G	KDDI
TS3H	KDDI
TS3I	KDDI
TS3J	KDDI
TS3K	KDDI

TS3L	KDDI
TS3M	KDDI
TS3N	KDDI
TS3O	KDDI
TS3P	KDDI
TS3R	KDDI
KONKA_D263	Konka
Buckle	Kyocera
E1000	Kyocera
E2000	Kyocera
E4000	Kyocera
Glide	Kyocera
K127	Kyocera
K24	Kyocera
KWC-K612	Kyocera
KWC-K612B	Kyocera
KX18	Kyocera
KX5	Kyocera
Lightpipe	Kyocera
M1000	Kyocera
M2000	Kyocera
M2000-ZQ	Kyocera
S1300	Kyocera
S2000i	Kyocera
s2410	Kyocera
S4000	Kyocera
WX340K	Kyocera
D450B	LCT
D500B	LCT
D800B	LCT
L300B	LCT
L310B	LCT
TV320B	LCT
TV900B	LCT
X700B	LCT
X845B	LCT
X880B	LCT
IQ 707	Lemon
E307	Lenovo
ET600	Lenovo
ET860	Lenovo
i919	Lenovo
i921	Lenovo
i966	Lenovo
P708	Lenovo
P780	Lenovo
V800	Lenovo
	210 LG
	550 LG
	5500 LG
5500-parrot	LG
	7100 LG

7100-parrot	LG
	8100 LG
	8500 LG
	8560 LG
	8600 LG
	8700 LG
	8800 LG
	9100 LG
	9200 LG
	9700 LG
AD6335	LG
AX260	LG
AX300	LG
AX500	LG
AX585	LG
AX830	LG
B2000	LG
B2050	LG
B2060	LG
B2070	LG
B2100	LG
B2150	LG
Bliss UX700	LG
C1100	LG
C1150	LG
C1200	LG
C1300	LG
C1500	LG
C2000	LG
C2100	LG
C2200	LG
C2500	LG
C3100	LG
C3300	LG
C3310	LG
C3320	LG
C3380	LG
C3400	LG
C3600	LG
CB630	LG
CE110	LG
CE500	LG
CF360	LG
CG180	LG
CG225	LG
CG300	LG
Chocolate BL20	LG
Chocolate BL40	LG
Chocolate BL42	LG
Chocolate Touch VX8575	LG
CP150	LG
CT810	LG

CU400	LG
CU405	LG
CU500	LG
CU515	LG
CU575	LG
CU720	LG
CU915	LG
CU920	LG
CX10000	LG
CX700	LG
enV Touch	LG
F2100	LG
F2250	LG
F2300	LG
F2400	LG
F2410	LG
F2500	LG
F3000	LG
F7250	LG
G1500	LG
G1600	LG
G1610	LG
G1800	LG
G252	LG
G262	LG
G3100	LG
G5200	LG
G5220C	LG
G5300	LG
G5300i	LG
G5310	LG
G5400	LG
G7000	LG
G7050	LG
G7070	LG
G7100	LG
G7120	LG
G7200	LG
G8000	LG
G912	LG
G920	LG
G933	LG
GB210	LG
GB220	LG
GB230	LG
GB250	LG
GC900 - Viewty Smart	LG
GD330	LG
GD510	LG
GD550	LG
GD880	LG
GD900	LG

GM200	LG
GM205	LG
GM310	LG
GM360	LG
GM730	LG
GM750	LG
GR500	LG
GR500R	LG
GR501	LG
GS390	LG
GS500	LG
GT360	LG
GT365	LG
GT400	LG
GT500	LG
GT505	LG
GT540	LG
GT810H	LG
GU230	LG
GU280	LG
GW300	LG
GW520	LG
GW525	LG
GW620 Eve	LG
GW820	LG
GW825	LG
HB620	LG
HB620T	LG
Helix	LG
KB1500	LG
KB620	LG
KB770	LG
KC550	LG
KC780	LG
KC910 - Renoir	LG
KE260	LG
KE500	LG
KE520	LG
KE590	LG
KE590i	LG
KE600	LG
KE600E	LG
KE770	LG
KE800	LG
KE820	LG
KE850 - Prada	LG
KE970 - Shine	LG
KE990 - Viewty	LG
KF240	LG
KF300	LG
KF310	LG
KF311	LG

KF350	LG
KF390	LG
KF510	LG
KF600	LG
KF690	LG
KF700	LG
KF750 - Secret	LG
KF755 - Secret	LG
KF757 - Secret	LG
KF900 - Prada II	LG
KG110	LG
KG119	LG
KG120	LG
KG130	LG
KG195	LG
KG200j	LG
KG208	LG
KG220	LG
KG225	LG
KG240	LG
KG245	LG
KG280	LG
KG290	LG
KG291i	LG
KG300	LG
KG320	LG
KG70	LG
KG800 - Chocolate	LG
KG810	LG
KG90	LG
KG920	LG
KH1300	LG
KM335	LG
KM380	LG
KM500	LG
KM555	LG
KM570	LG
KM710	LG
KM900 - Arena	LG
KP110	LG
KP115	LG
KP130	LG
KP135	LG
KP170	LG
KP175	LG
KP199	LG
KP200	LG
KP202	LG
KP202i	LG
KP210	LG
KP215	LG
KP220	LG

KP230	LG
KP233	LG
KP235	LG
KP260	LG
KP265	LG
KP270	LG
KP275	LG
KP293i	LG
KP320	LG
KP500	LG
KP501	LG
KP502	LG
KP550	LG
KP570	LG
KS10	LG
KS20	LG
KS360	LG
KS500	LG
KS660	LG
KT520	LG
KT525	LG
KT610	LG
KT615	LG
KU250	LG
KU311	LG
KU380	LG
KU385	LG
KU450	LG
KU580	LG
KU730	LG
KU800 - Chocolate	LG
KU830	LG
KU900	LG
KU950	LG
KU970 - Shine	LG
KU990 - Viewty	LG
L1100	LG
L1400	LG
L3100	LG
L341i-t	LG
L342i	LG
L343i	LG
L5100	LG
L600V	LG
L6imode	LG
LG Eve	LG
LG-ME970	LG
LG10000	LG
LG125	LG
LG150	LG
LG160P	LG
LG160V	LG

LG2000	LG
LG220C	LG
LG225	LG
LG240	LG
LG245	LG
LG260	LG
LG265	LG
LG280	LG
LG285	LG
LG290C	LG
LG325	LG
LG3300	LG
LG380	LG
LG385	LG
LG490	LG
LG5400	LG
LG570	LG
LG570V	LG
LG600	LG
LG6190	LG
LG6200	LG
LG700	LG
LG800	LG
LG830	LG
LG840	LG
LG8550	LG
LG8600	LG
LG9600	LG
LX165	LG
LX260	LG
LX265	LG
LX370	LG
LX550	LG
LX570	LG
LX600	LG
LX610	LG
M4410	LG
M6100	LG
MG105	LG
MG110	LG
MG120	LG
MG130	LG
MG185	LG
MG235	LG
MG280	LG
MG280c	LG
MG280d	LG
MG295	LG
MG300D	LG
MG320c	LG
MG800	LG
MG810C	LG

MS20	LG
MS25	LG
MT375	LG
MU500	LG
MU515	LG
MX200	LG
MX275	LG
MX300	LG
MX380	LG
MX500	LG
MX505	LG
MX510	LG
MX830	LG
MX8500	LG
MX8550	LG
MX8700	LG
MX9700	LG
OG200	LG
P7200	LG
PLS150	LG
PLS225	LG
RGSC1500	LG
S5000	LG
S5100	LG
S5200	LG
Shine	LG
T5100	LG
TE365	LG
TG800	LG
TM250	LG
Touch AX8575	LG
Tritan	LG
TU330	LG
TU500	LG
TU515	LG
TU550	LG
TU575	LG
TU720	LG
TU750	LG
TU915	LG
U250	LG
U300	LG
U310	LG
U370	LG
U400	LG
U450	LG
U8110	LG
U8120	LG
U8130	LG
U8138	LG
U8150	LG
U8180	LG

U8210	LG
U8290	LG
U830	LG
U8330	LG
U8360	LG
U8380	LG
U8500	LG
U8550	LG
U880	LG
U890	LG
U900	LG
U960	LG
U970	LG
U990	LG
V9000	LG
VM265	LG
VX10000	LG
VX5400	LG
VX5500	LG
VX8300	LG
VX8350	LG
VX8360	LG
VX8500	LG
VX8550	LG
VX8560	LG
VX8610	LG
VX8700	LG
VX8800	LG
VX9100	LG
VX9200	LG
VX9400	LG
VX9600	LG
VX9700	LG
VX9900	LG
SK16D	Longcos
SK18	Longcos
M8	Meizu
Q5	Micromax
Zune HD	Microsoft
MOI 8380	MiTAC
FOMA D903iTV	Mitsubishi
M341i	Mitsubishi
M342i	Mitsubishi
M420i	Mitsubishi
M430i	Mitsubishi
OT531	Mitsubishi
Zinc II	Mobile & Wireless Group
Jama	MobileXP
EL480	Mobistel
EL580	Mobistel
Elite EML2	ModeLabs
HT-2	ModeLabs

Hummer HT1	ModeLabs
Levis the original	Modelabs
MTV3-3	ModeLabs
myway Slim	ModeLabs
V-Touch	ModeLabs
Virgin_1	ModeLabs
	398 Motorola
A-1C	Motorola
A-2B	Motorola
A-6E	Motorola
A-8A	Motorola
A-8D	Motorola
A-A4	Motorola
A-A6	Motorola
A-B7	Motorola
A1000	Motorola
A1200eam	Motorola
A1200r	Motorola
A1600	Motorola
A3100	Motorola
A455	Motorola
A630	Motorola
A780	Motorola
A810	Motorola
A835	Motorola
A910	Motorola
A920	Motorola
A925	Motorola
AURA	Motorola
C155	Motorola
C168	Motorola
C257	Motorola
C261	Motorola
C290-boost	Motorola
C350	Motorola
C380	Motorola
C381p	Motorola
C385	Motorola
c390	Motorola
c450	Motorola
C550	Motorola
C650	Motorola
C975	Motorola
C980M	Motorola
Calgary (A555)	Motorola
Dext	Motorola
Droid	Motorola
E1	Motorola
E1000	Motorola
E1070	Motorola
E365	Motorola
E378i	Motorola

E380	Motorola
E398	Motorola
E550	Motorola
E680	Motorola
E680i	Motorola
E770	Motorola
E770v	Motorola
E8	Motorola
E815	Motorola
EM25	Motorola
EM28	Motorola
EM30	Motorola
EM325	Motorola
EM330	Motorola
EOKR Z6	Motorola
GENETIK3	Motorola
i290	Motorola
i425	Motorola
i576	Motorola
i580	Motorola
i850	Motorola
i870	Motorola
i877	Motorola
ic502	Motorola
ic902	Motorola
K1	Motorola
K1c	Motorola
K1m	Motorola
K3	Motorola
KRZR K1c	Motorola
L2	Motorola
L6	Motorola
L7	Motorola
L9	Motorola
MB300	Motorola
MILLA	Motorola
MotoMB200	Motorola
MotoQ	Motorola
MotoQA1	Motorola
MOTORIZR-Z8	Motorola
MOTOROKR E1	Motorola
MOTOROKR E6	Motorola
MOTOROKR Z6	Motorola
MOTOZ9	Motorola
MPx	Motorola
MPx220	Motorola
Opus One	Motorola
PAN4	Motorola
PEBL	Motorola
Q11	Motorola
Q8	Motorola
Q9	Motorola

Q9c	Motorola
Q9H	Motorola
QA30	Motorola
R38	Motorola
RAZR V3m	Motorola
RAZR V8	Motorola
RAZR V9	Motorola
RAZRV3x	Motorola
RAZRV3xx	Motorola
RAZRV6	Motorola
ROKR E2	Motorola
Ruth	Motorola
Spark	Motorola
T720	Motorola
TA02	Motorola
U9	Motorola
V1050	Motorola
V1075	Motorola
V1100	Motorola
v150	Motorola
V171	Motorola
V177	Motorola
V180	Motorola
V188	Motorola
V190	Motorola
V191	Motorola
V195	Motorola
V197	Motorola
V220	Motorola
V235	Motorola
V265	Motorola
V3	Motorola
V300	Motorola
V323i	Motorola
v325	Motorola
V360	Motorola
V3c	Motorola
V3i	Motorola
V3m	Motorola
V400	Motorola
V500	Motorola
V501	Motorola
V505	Motorola
V525	Motorola
V535	Motorola
V540	Motorola
V545	Motorola
V547	Motorola
V550	Motorola
V551	Motorola
V555	Motorola
V557	Motorola

V560	Motorola
V600	Motorola
V620	Motorola
V635	Motorola
V710	Motorola
V750	Motorola
V8	Motorola
V80	Motorola
V950	Motorola
V975	Motorola
V980	Motorola
V9m	Motorola
V9mm	Motorola
VA76r	Motorola
VE20	Motorola
VE240	Motorola
VE440	Motorola
VE465	Motorola
VE538	Motorola
VE595	Motorola
VE66	Motorola
VEGAS	Motorola
W220	Motorola
W230	Motorola
W231	Motorola
W233	Motorola
W270	Motorola
W360	Motorola
W370	Motorola
W375	Motorola
W376g	Motorola
W377	Motorola
W385	Motorola
W385m	Motorola
W388	Motorola
W396	Motorola
W397	Motorola
W450	Motorola
W5	Motorola
W510	Motorola
W755	Motorola
W766	Motorola
W840	Motorola
WX280	Motorola
WX395	Motorola
XT800	Motorola
Z3	Motorola
Z6m	Motorola
ZN200	Motorola
ZN300	Motorola
ZN4	Motorola
ZN5	Motorola

Touch	myWAY
	6206 NEC
A525	NEC
c616	NEC
E101	NEC
E121	NEC
E122	NEC
E132	NEC
E232	NEC
E242	NEC
E313	NEC
e338	NEC
e353	NEC
e540	NEC
e949	NEC
N21i	NEC
N223i	NEC
N22i	NEC
N331	NEC
N341i	NEC
N342i	NEC
N343i	NEC
N400i	NEC
N401i	NEC
N410i	NEC
N411i	NEC
N500i	NEC
N600	NEC
N600i	NEC
N820	NEC
N850	NEC
E2831	Neuf
V08	Newplan
NX-G911	Nexian
NX-G922	Nexian
DSi	Nintendo
	1006 Nokia
	1606 Nokia
1680 classic	Nokia
1681c	Nokia
2125i	Nokia
2220s	Nokia
	2228 Nokia
2323 classic	Nokia
2330 classic	Nokia
2600 classic	Nokia
	2610 Nokia
	2626 Nokia
	2630 Nokia
	2650 Nokia
	2660 Nokia
	2680 Nokia

	2690 Nokia
2700 classic	Nokia
2720 fold	Nokia
2730c	Nokia
	2760 Nokia
2855i	Nokia
	2865 Nokia
2865i	Nokia
	3100 Nokia
	3108 Nokia
3109 classic	Nokia
3110 classic	Nokia
	3120 Nokia
3120 classic	Nokia
	3128 Nokia
	3200 Nokia
	3205 Nokia
	3220 Nokia
	3230 Nokia
	3250 Nokia
	3300 Nokia
	3410 Nokia
3500 classic	Nokia
	3510 Nokia
3510i	Nokia
3555b	Nokia
3555c	Nokia
	3600 Nokia
3600 slide	Nokia
	3606 Nokia
3610 fold	Nokia
	3650 Nokia
	3660 Nokia
3710fold	Nokia
3720 classic	Nokia
	5000 Nokia
	5070 Nokia
	5100 Nokia
5130 XpressMusic	Nokia
	5140 Nokia
5140i	Nokia
	5200 Nokia
	5208 Nokia
5220 XpressMusic	Nokia
	5230 Nokia
	5233 Nokia
5300 XpressMusic	Nokia
5310 XpressMusic	Nokia
	5320 Nokia
5320 XpressMusic	Nokia
5530 XpressMusic	Nokia
5610 XpressMusic	Nokia

5630 XpressMusic	Nokia
5700 XpressMusic	Nokia
5730 XpressMusic	Nokia
5800 XpressMusic	Nokia
	5802 Nokia
6016i	Nokia
	6020 Nokia
	6021 Nokia
	6030 Nokia
	6060 Nokia
	6066 Nokia
	6070 Nokia
	6080 Nokia
	6085 Nokia
	6086 Nokia
	6088 Nokia
	6100 Nokia
	6101 Nokia
	6102 Nokia
	6103 Nokia
	6108 Nokia
6110 Navigator	Nokia
	6111 Nokia
	6120 Nokia
6120 classic	Nokia
6121 classic	Nokia
6122c	Nokia
	6125 Nokia
	6126 Nokia
	6131 Nokia
	6133 Nokia
	6136 Nokia
	6151 Nokia
	6170 Nokia
6208c	Nokia
	6210 Nokia
6210 Navigator	Nokia
6212 classic	Nokia
6220 classic	Nokia
	6230 Nokia
6230i	Nokia
	6233 Nokia
	6234 Nokia
	6235 Nokia
	6260 Nokia
	6263 Nokia
	6265 Nokia
6265i	Nokia
	6267 Nokia
	6270 Nokia
	6275 Nokia
6275i	Nokia

	6276 Nokia
	6280 Nokia
	6288 Nokia
	6290 Nokia
	6300 Nokia
	6301 Nokia
6303 classic	Nokia
6303c	Nokia
6303i	Nokia
6310i	Nokia
	6350 Nokia
6350-1d	Nokia
	6500 Nokia
6500 classic	Nokia
6500 slide	Nokia
	6510 Nokia
	6555 Nokia
	6585 Nokia
6600 fold	Nokia
6600 slide	Nokia
	6610 Nokia
	6620 Nokia
	6630 Nokia
	6650 Nokia
	6670 Nokia
	6680 Nokia
	6681 Nokia
	6682 Nokia
	6700 Nokia
6700 classic	Nokia
	6708 Nokia
6710 Navigator	Nokia
6720 classic	Nokia
6730 classic	Nokia
6760 slide	Nokia
	6788 Nokia
6790s	Nokia
	6800 Nokia
	6810 Nokia
	6820 Nokia
	6822 Nokia
	6880 Nokia
	7020 Nokia
	7070 Nokia
7100 Supernova	Nokia
	7110 Nokia
	7200 Nokia
7210 Supernova	Nokia
	7230 Nokia
	7250 Nokia
7250i	Nokia
	7260 Nokia

	7270 Nokia
	7280 Nokia
7310 Supernova	Nokia
	7360 Nokia
	7370 Nokia
	7373 Nokia
	7380 Nokia
	7390 Nokia
7500 Prism	Nokia
7510 Supernova	Nokia
	7600 Nokia
7610 Supernova	Nokia
	7650 Nokia
	7710 Nokia
7900 Prism	Nokia
	8310 Nokia
8600 Luna	Nokia
	8800 Nokia
8910i	Nokia
	9210 Nokia
	9300 Nokia
	9500 Nokia
	9610 Nokia
C5-00	Nokia
E5	Nokia
E50	Nokia
E51	Nokia
E52	Nokia
E55	Nokia
E60	Nokia
E61	Nokia
E61i	Nokia
E62	Nokia
E63	Nokia
E65	Nokia
E66	Nokia
E70	Nokia
E71	Nokia
E72	Nokia
E75	Nokia
E90	Nokia
N-Gage	Nokia
N-GageQD	Nokia
N70	Nokia
N71	Nokia
N72	Nokia
N73	Nokia
N75	Nokia
N76	Nokia
N77	Nokia
N78	Nokia
N79	Nokia

N80	Nokia
N81	Nokia
N82	Nokia
N85	Nokia
N86	Nokia
N86-3	Nokia
N90	Nokia
N91	Nokia
N92	Nokia
N93	Nokia
N93i	Nokia
N95	Nokia
N95 8GB	Nokia
N96	Nokia
N97	Nokia
NX3-00	Nokia
Vertu Ascent Ti	Nokia
X6	Nokia
C306	Novo
D703i	NTT DoCoMo
D704i	NTT DoCoMo
D705i	NTT DoCoMo
D800iDS	NTT DoCoMo
D902iS	NTT DoCoMo
D903i	NTT DoCoMo
D904i	NTT DoCoMo
D905i	NTT DoCoMo
F01A	NTT DoCoMo
F01B	NTT DoCoMo
F02A	NTT DoCoMo
F02B	NTT DoCoMo
F03A	NTT DoCoMo
F04A	NTT DoCoMo
F04B	NTT DoCoMo
F08A3	NTT DoCoMo
F09A3	NTT DoCoMo
F705i	NTT DoCoMo
F706i	NTT DoCoMo
F900iC	NTT DoCoMo
F902iS	NTT DoCoMo
F903i	NTT DoCoMo
F904i	NTT DoCoMo
F905i	NTT DoCoMo
G402i	NTT DoCoMo
L01A	NTT DoCoMo
L03A	NTT DoCoMo
L705iX	NTT DoCoMo
M702iS	NTT DoCoMo
N-03A	NTT DoCoMo
N01A	NTT DoCoMo
N01B	NTT DoCoMo
N02A	NTT DoCoMo

N03B	NTT DoCoMo
N04A	NTT DoCoMo
N05A	NTT DoCoMo
N06A3	NTT DoCoMo
N07A3	NTT DoCoMo
N08A3	NTT DoCoMo
N09A3	NTT DoCoMo
N505i	NTT DoCoMo
N506iS	NTT DoCoMo
N702iD	NTT DoCoMo
N703iD	NTT DoCoMo
N705i	NTT DoCoMo
N706i	NTT DoCoMo
N900i	NTT DoCoMo
N902iS	NTT DoCoMo
N902iX	NTT DoCoMo
N903i	NTT DoCoMo
N904i	NTT DoCoMo
N905i	NTT DoCoMo
N905imyu	NTT DoCoMo
N906i	NTT DoCoMo
NM705i	NTT DoCoMo
NM850iG	NTT DoCoMo
P01A	NTT DoCoMo
P01B	NTT DoCoMo
P02A	NTT DoCoMo
P03A	NTT DoCoMo
P03B	NTT DoCoMo
P04A	NTT DoCoMo
P05A	NTT DoCoMo
P06A	NTT DoCoMo
P07A3	NTT DoCoMo
P08A3	NTT DoCoMo
P10A	NTT DoCoMo
P703i	NTT DoCoMo
P703imyu	NTT DoCoMo
P704i	NTT DoCoMo
P705i	NTT DoCoMo
P706imyu	NTT DoCoMo
P900iV	NTT DoCoMo
P902i	NTT DoCoMo
P902iS	NTT DoCoMo
P903i	NTT DoCoMo
P904i	NTT DoCoMo
P905i	NTT DoCoMo
P906i	NTT DoCoMo
P90liS	NTT DoCoMo
S710i	NTT DoCoMo
SH01A	NTT DoCoMo
SH01B	NTT DoCoMo
SH02A	NTT DoCoMo
SH02B	NTT DoCoMo

SH03A	NTT DoCoMo
SH03B	NTT DoCoMo
SH04A	NTT DoCoMo
SH05A3	NTT DoCoMo
SH06A3	NTT DoCoMo
SH703i	NTT DoCoMo
SH705i	NTT DoCoMo
SH706i	NTT DoCoMo
SH851i	NTT DoCoMo
SH902i	NTT DoCoMo
SH903i	NTT DoCoMo
SH904i	NTT DoCoMo
SH906i	NTT DoCoMo
SO502i	NTT DoCoMo
SO702i	NTT DoCoMo
SO703i	NTT DoCoMo
SO705i	NTT DoCoMo
SO706i	NTT DoCoMo
SO903i	NTT DoCoMo
SO903iTV	NTT DoCoMo
SO905i	NTT DoCoMo
SO906i	NTT DoCoMo
Atmos	O2
Graphite	O2
X1	O2
X1b	O2
X1i	O2
X2i	O2
Xda 2s	O2
Xda Comet	O2
Xda Stealth	O2
N5000	Onda Communication S.P.A
N5020	Onda Communication S.P.A
N5050	Onda Communication S.P.A
N7100	Onda Communication S.P.A
n725	ORSiO
Blazer	Palm
PalmOne Tungsten T3	Palm
Pré	Palm
Treo 500	Palm
Treo 650	Palm
Treo 680	Palm
Treo 700p	Palm
Treo 700wx	Palm
Treo 750	Palm
Treo 800w	Palm
Treo 850	Palm
Tunx	Palm
TX	Palm
705P	Panasonic
810P	Panasonic
820P	Panasonic

822P	Panasonic
823P	Panasonic
830P	Panasonic
831P	Panasonic
832P	Panasonic
920P	Panasonic
940P	Panasonic
A210	Panasonic
G50	Panasonic
G60	Panasonic
G70	Panasonic
GAD6	Panasonic
GAD67	Panasonic
GAD87	Panasonic
MX6	Panasonic
P341i	Panasonic
SC3	Panasonic
SoftBank/1.0/921P	Panasonic
VS3	Panasonic
VS6	Panasonic
X100	Panasonic
X200	Panasonic
X300	Panasonic
X400	Panasonic
X500	Panasonic
X60	Panasonic
X66	Panasonic
X70	Panasonic
X700	Panasonic
	3500 Pantech
C530	Pantech
C740	Pantech
C790	Pantech
C810	Pantech
CDM8935	Pantech
COCOON	Pantech
EUROPA-U4000	Pantech
G300	Pantech
GF200	Pantech
PG-1310V	Pantech
PG-3210	Pantech
PG-3900J	Pantech
PG1200	Pantech
Shuttle	Pantech
TX215	Pantech
	162 Philips
	350 Philips
	355 Philips
	362 Philips
	530 Philips
	535 Philips
	568 Philips

598 Philips
636 Philips
639 Philips
662 Philips
755 Philips
760 Philips
855 Philips

FISIO 620	Philips
FISIO 820	Philips
FISIO 822	Philips
FISIO 825	Philips
PHILIPS9A9W	Philips
X520	Philips
X800	Philips
Xenium X710	Philips
S108	PhoneOne
S901	PhoneOne
P9521	Porsche
W601	Postcom
Wget	RedShift
D09	Ron
S5	RoverPC
CO210	Sagem
MC2007	Sagem
my201	Sagem
my202	Sagem
my202C	Sagem
my212X	Sagem
my213	Sagem
my300C	Sagem
my300X	Sagem
my301X	Sagem
my302X	Sagem
my312X	Sagem
my400V	Sagem
my400X	Sagem
my401C	Sagem
my401Ci	Sagem
my401X	Sagem
my401Z	Sagem
my405X	Sagem
my411C	Sagem
my411V	Sagem
my411X	Sagem
my411Xi	Sagem
my418X	Sagem
my419x	Sagem
my421Z	Sagem
my429x	Sagem
My433v	Sagem
my501C	Sagem
my501Ci	Sagem

my501X	Sagem
my511X	Sagem
my519x	Sagem
my521X	Sagem
my600v	Sagem
my600x	Sagem
my700x	Sagem
my700Xi	Sagem
my721X	Sagem
my730C	Sagem
my750X	Sagem
my800v	Sagem
my810x	Sagem
my850C	Sagem
my850V	Sagem
my901C	Sagem
myC-2	Sagem
myC-3	Sagem
myC-4	Sagem
myC2-2	Sagem
myC2-3	Sagem
myC3-2	Sagem
myC4-2	Sagem
myC5-2	Sagem
myC5-2T	Sagem
myC5-2v	Sagem
myC5-3	Sagem
myC5-3i	Sagem
MyMobileTv	Sagem
myS-7	Sagem
myV-55	Sagem
myV-56	Sagem
myV-65	Sagem
myV-75	Sagem
myV-76	Sagem
myV-85	Sagem
myV201	Sagem
myW-7	Sagem
myX-1	Sagem
myX-2	Sagem
myx-3	Sagem
myX-4	Sagem
myX-4T	Sagem
myX-5	Sagem
myX-5-2T	Sagem
myX-5m	Sagem
myX-6	Sagem
myX-7	Sagem
myX-8	Sagem
myX2-2	Sagem
myX3	Sagem
myX3-2	Sagem

myX5-2	Sagem
myX5-2m	Sagem
myX6-2	Sagem
myX6-2/1.0	Sagem
myX8	Sagem
myZ-5	Sagem
PORSCHE-DESIGN-P-9522	Sagem
Puma Phone	Sagem
SG321i	Sagem
SG322i	Sagem
SG341i	Sagem
SG342i	Sagem
SG343i	Sagem
SG344i	Sagem
SG345i	Sagem
SG346i	Sagem
VF526	Sagem
VF527	Sagem
706SC	Samsung
707SC	Samsung
707SC2	Samsung
821SC	Samsung
920SC	Samsung
931SC	Samsung
B2100	Samsung
B3210	Samsung
B3310	Samsung
B5310	Samsung
B5702	Samsung
B5712C	Samsung
Behold2	Samsung
C3010	Samsung
C3050	Samsung
C3053	Samsung
C3110	Samsung
C5130	Samsung
C5212	Samsung
C5220	Samsung
C5510	Samsung
C6620	Samsung
C6625	Samsung
Caliber	Samsung
Corby	Samsung
E1310B	Samsung
E1360	Samsung
E1360B	Samsung
E1410	Samsung
E2100	Samsung
E2120	Samsung
E2130	Samsung
E2210	Samsung
E2210B	Samsung

E250	Samsung
E2510	Samsung
Fellow	Samsung
Galaxy	Samsung
Galaxy Spica	Samsung
GT-B3313	Samsung
GT-B3410	Samsung
GT-B5722	Samsung
GT-B7330	Samsung
GT-B7620	Samsung
GT-C3060	Samsung
GT-C3212	Samsung
GT-C3510	Samsung
GT-C6112	Samsung
GT-E1130B	Samsung
GT-I6410	Samsung
GT-I8320	Samsung
GT-I8510C	Samsung
GT-M2513	Samsung
GT-M2520	Samsung
GT-M5650	Samsung
GT-S3370	Samsung
GT-S3600C	Samsung
GT-S3600i	Samsung
GT-S5150	Samsung
GT-S5230	Samsung
GT-S5233T	Samsung
GT-S5350	Samsung
GT-S5500	Samsung
GT-S5503	Samsung
GT-S5510	Samsung
GT-S5550	Samsung
GT-S5560	Samsung
GT-S5620	Samsung
GT-S6700	Samsung
GT-S7070	Samsung
GT-S7550	Samsung
GT-S8000	Samsung
GT-S8000C	Samsung
GT-S8000L	Samsung
GT-S8500	Samsung
i7110	Samsung
I7500	Samsung
Jet	Samsung
JetSet	Samsung
M2310	Samsung
M2510	Samsung
M2710	Samsung
M3510	Samsung
M7500	Samsung
M8920	Samsung
Omnia II	Samsung

Omnia Lite	Samsung
Omnia Pro B7320	Samsung
Omnia Pro B7610	Samsung
Platine	Samsung
Player Addict	Samsung
Player Duo	Samsung
Player HD	Samsung
Player One	Samsung
Player Pixon	Samsung
Player Pixon 12	Samsung
Player Star	Samsung
Player Star WiFi	Samsung
Player Style	Samsung
Player Ultra	Samsung
S3030	Samsung
S3100	Samsung
S3110	Samsung
S3310	Samsung
S3500	Samsung
S3600	Samsung
S5050	Samsung
S5200	Samsung
S5230	Samsung
S7220	Samsung
S7350	Samsung
Saturn	Samsung
SCH-A645	Samsung
SCH-A870	Samsung
SCH-A900	Samsung
SCH-A915	Samsung
SCH-A930	Samsung
SCH-A950	Samsung
SCH-F309	Samsung
SCH-F339	Samsung
SCH-i220	Samsung
SCH-i760	Samsung
SCH-i770	Samsung
SCH-L768	Samsung
SCH-M710	Samsung
SCH-N485	Samsung
SCH-R210	Samsung
SCH-R211	Samsung
SCH-R300	Samsung
SCH-r310 Byline	Samsung
SCH-R330	Samsung
SCH-r350	Samsung
SCH-R351	Samsung
SCH-R400	Samsung
SCH-R410	Samsung
SCH-R420	Samsung
SCH-R430	Samsung
SCH-R450	Samsung

SCH-R451	Samsung
SCH-R500	Samsung
SCH-R561	Samsung
SCH-R600	Samsung
SCH-R610	Samsung
SCH-R800 Delve	Samsung
SCH-R810	Samsung
SCH-S259	Samsung
SCH-S319	Samsung
SCH-U340	Samsung
SCH-U350	Samsung
SCH-U410	Samsung
SCH-U430	Samsung
SCH-U440	Samsung
SCH-U450	Samsung
SCH-U450-parrot	Samsung
SCH-U490	Samsung
SCH-U520	Samsung
SCH-U540	Samsung
SCH-U550	Samsung
SCH-U620	Samsung
SCH-U650	Samsung
SCH-U700	Samsung
SCH-U740	Samsung
SCH-U750L	Samsung
SCH-U810	Samsung
SCH-U900	Samsung
SCH-U940	Samsung
SCH-U960	Samsung
SCHR100	Samsung
SEC-SGH-A127	Samsung
SEC-SGH-B200	Samsung
SEC-SGH-B270	Samsung
SEC-SGH-D406	Samsung
SEC-SGH-D418	Samsung
SEC-SGH-D59	Samsung
SEC-SGH-E715	Samsung
SEC-SGH-I321N	Samsung
SEC-SGH-P735	Samsung
SEC-SGH-P777	Samsung
SEC-SGH-U900	Samsung
SGH-560	Samsung
SGH-860V	Samsung
SGH-A117	Samsung
SGH-A137	Samsung
SGH-A167	Samsung
SGH-A177	Samsung
SGH-A226	Samsung
SGH-A227	Samsung
SGH-A237	Samsung
SGH-A256	Samsung
SGH-A257	Samsung

SGH-A288	Samsung
SGH-A300	Samsung
SGH-A411	Samsung
SGH-A412	Samsung
SGH-A436	Samsung
SGH-A437	Samsung
SGH-A501	Samsung
SGH-A516	Samsung
SGH-A517	Samsung
SGH-A551	Samsung
SGH-A561	Samsung
SGH-A637	Samsung
SGH-A687	Samsung
SGH-A701	Samsung
SGH-A706	Samsung
SGH-A707	Samsung
SGH-A717	Samsung
SGH-A727	Samsung
SGH-A736	Samsung
SGH-A737	Samsung
SGH-A746	Samsung
SGH-A747	Samsung
SGH-A766	Samsung
SGH-A767	Samsung
SGH-A777	Samsung
SGH-A796	Samsung
SGH-A797	Samsung
SGH-A800	Samsung
SGH-A801	Samsung
SGH-A811	Samsung
SGH-A821	Samsung
SGH-A827	Samsung
SGH-A836	Samsung
SGH-A837	Samsung
SGH-A867	Samsung
SGH-A877	Samsung
SGH-A885	Samsung
SGH-A886	Samsung
SGH-A887	Samsung
SGH-A897	Samsung
SGH-B100	Samsung
SGH-B110L	Samsung
SGH-B130	Samsung
SGH-B220	Samsung
SGH-B2700	Samsung
SGH-B270i	Samsung
SGH-B300	Samsung
SGH-B310	Samsung
SGH-B320	Samsung
SGH-B500	Samsung
SGH-B510	Samsung
SGH-B520	Samsung

SGH-B520V	Samsung
SGH-C100G	Samsung
SGH-C130	Samsung
SGH-C140	Samsung
SGH-C158	Samsung
SGH-C160	Samsung
SGH-C161	Samsung
SGH-C165	Samsung
SGH-C166	Samsung
SGH-C170	Samsung
SGH-C180	Samsung
SGH-C200	Samsung
SGH-C210	Samsung
SGH-C216	Samsung
SGH-C230	Samsung
SGH-C250	Samsung
SGH-C260M	Samsung
SGH-C268	Samsung
SGH-C270	Samsung
SGH-C276	Samsung
SGH-C280	Samsung
SGH-C300	Samsung
SGH-C308	Samsung
SGH-C327	Samsung
SGH-C400	Samsung
SGH-C416	Samsung
SGH-C417	Samsung
SGH-C425	Samsung
SGH-C426	Samsung
SGH-C450	Samsung
SGH-C506	Samsung
SGH-C516	Samsung
SGH-C520	Samsung
SGH-D347	Samsung
SGH-D357	Samsung
SGH-D407	Samsung
SGH-D410	Samsung
SGH-D500	Samsung
SGH-D508	Samsung
SGH-D510	Samsung
SGH-D520	Samsung
SGH-D528	Samsung
SGH-D600	Samsung
SGH-D600E	Samsung
SGH-D608	Samsung
SGH-D720	Samsung
SGH-D730	Samsung
SGH-D780	Samsung
SGH-D788	Samsung
SGH-D800	Samsung
SGH-D807	Samsung
SGH-D808	Samsung

SGH-D820	Samsung
SGH-D830	Samsung
SGH-D836	Samsung
SGH-D840	Samsung
SGH-D848	Samsung
SGH-D880	Samsung
SGH-D888	Samsung
SGH-D900	Samsung
SGH-D900e	Samsung
SGH-D908	Samsung
SGH-D988	Samsung
SGH-E116	Samsung
SGH-E200	Samsung
SGH-E210	Samsung
SGH-E215	Samsung
SGH-E250	Samsung
SGH-E251	Samsung
SGH-E256	Samsung
SGH-E258	Samsung
SGH-E300	Samsung
SGH-E310	Samsung
SGH-E315	Samsung
SGH-E330	Samsung
SGH-E340	Samsung
SGH-E350	Samsung
SGH-E360	Samsung
SGH-E368	Samsung
SGH-E370	Samsung
SGH-E376	Samsung
SGH-E380	Samsung
SGH-E390	Samsung
SGH-E420	Samsung
SGH-E488	Samsung
SGH-E490	Samsung
SGH-E496	Samsung
SGH-E498	Samsung
SGH-E500	Samsung
SGH-E530	Samsung
SGH-E570	Samsung
SGH-E576	Samsung
SGH-E590	Samsung
SGH-E600	Samsung
SGH-E620	Samsung
SGH-E630	Samsung
SGH-E635	Samsung
SGH-E640	Samsung
SGH-E690	Samsung
SGH-E700	Samsung
SGH-E708	Samsung
SGH-E710	Samsung
SGH-E720	Samsung
SGH-E728	Samsung

SGH-E730	Samsung
SGH-E736	Samsung
SGH-E738	Samsung
SGH-E740	Samsung
SGH-E746	Samsung
SGH-E747	Samsung
SGH-E760	Samsung
SGH-E770	Samsung
SGH-E780	Samsung
SGH-E790	Samsung
SGH-E800	Samsung
SGH-E808	Samsung
SGH-E810	Samsung
SGH-E820	Samsung
SGH-E830	Samsung
SGH-E840	Samsung
SGH-E848	Samsung
SGH-E850	Samsung
SGH-E870	Samsung
SGH-E880	Samsung
SGH-E890	Samsung
SGH-E898	Samsung
SGH-E900	Samsung
SGH-E908	Samsung
SGH-E950	Samsung
SGH-E958	Samsung
SGH-F110	Samsung
SGH-F200	Samsung
SGH-F210	Samsung
SGH-F250	Samsung
SGH-F258	Samsung
SGH-F265L	Samsung
SGH-F266	Samsung
SGH-F268	Samsung
SGH-F270	Samsung
SGH-F275L	Samsung
SGH-F300	Samsung
SGH-F308	Samsung
SGH-F310	Samsung
SGH-F330	Samsung
SGH-F338	Samsung
SGH-F400	Samsung
SGH-F406	Samsung
SGH-F490	Samsung
SGH-F500	Samsung
SGH-F700	Samsung
SGH-G400	Samsung
SGH-G600	Samsung
SGH-G608	Samsung
SGH-G800	Samsung
SGH-G808	Samsung
SGH-G810	Samsung

SGH-G818E	Samsung
SGH-i200	Samsung
SGH-i300	Samsung
SGH-i320	Samsung
SGH-i400	Samsung
SGH-i450	Samsung
SGH-i458	Samsung
SGH-i520V	Samsung
SGH-i550	Samsung
SGH-i560	Samsung
SGH-i600	Samsung
SGH-i601	Samsung
SGH-i607	Samsung
SGH-i616	Samsung
SGH-i617	Samsung
SGH-i620	Samsung
SGH-i620V	Samsung
SGH-i627	Samsung
SGH-i637	Samsung
SGH-i640V	Samsung
SGH-i688	Samsung
SGH-i710	Samsung
SGH-i718	Samsung
SGH-i740	Samsung
SGH-i780	Samsung
SGH-i8510	Samsung
SGH-i907	Samsung
SGH-J150	Samsung
SGH-J200	Samsung
SGH-J208	Samsung
SGH-J210	Samsung
SGH-J400	Samsung
SGH-J600	Samsung
SGH-J600E	Samsung
SGH-J600V	Samsung
SGH-J608	Samsung
SGH-J610	Samsung
SGH-J630	Samsung
SGH-J700	Samsung
SGH-J706	Samsung
SGH-J708	Samsung
SGH-J750	Samsung
SGH-J770	Samsung
SGH-J800	Samsung
SGH-L170	Samsung
SGH-L288	Samsung
SGH-L310	Samsung
SGH-L320	Samsung
SGH-L400	Samsung
SGH-L600	Samsung
SGH-L700	Samsung
SGH-L708	Samsung

SGH-L760	Samsung
SGH-L768	Samsung
SGH-L770	Samsung
SGH-L810	Samsung
SGH-L810V	Samsung
SGH-L870	Samsung
SGH-M110	Samsung
SGH-M120	Samsung
SGH-M130L	Samsung
SGH-M140	Samsung
SGH-M140L	Samsung
SGH-M150	Samsung
SGH-M200	Samsung
SGH-M300	Samsung
SGH-M310	Samsung
SGH-M310V	Samsung
SGH-M3200	Samsung
SGH-M600	Samsung
SGH-M610	Samsung
SGH-M620	Samsung
SGH-M628	Samsung
SGH-N700	Samsung
SGH-P180	Samsung
SGH-P200	Samsung
SGH-P207	Samsung
SGH-P220	Samsung
SGH-P250	Samsung
SGH-P260	Samsung
SGH-P270	Samsung
SGH-P300	Samsung
SGH-P310	Samsung
SGH-P400	Samsung
SGH-P408	Samsung
SGH-P510	Samsung
SGH-P520	Samsung
SGH-P730	Samsung
SGH-P850	Samsung
SGH-P900	Samsung
SGH-P910	Samsung
SGH-P920	Samsung
SGH-P930	Samsung
SGH-P960	Samsung
SGH-R210s	Samsung
SGH-R460	Samsung
SGH-R560	Samsung
SGH-S100	Samsung
SGH-S300	Samsung
SGH-S300M	Samsung
SGH-S341i	Samsung
SGH-S342i	Samsung
SGH-S366	Samsung
SGH-S400i	Samsung

SGH-S401i	Samsung
SGH-S410i	Samsung
SGH-S500	Samsung
SGH-S500i	Samsung
SGH-S501i	Samsung
SGH-S720i	Samsung
SGH-S730i	Samsung
SGH-S7330	Samsung
SGH-T139	Samsung
SGH-T201G	Samsung
SGH-T209	Samsung
SGH-T219	Samsung
SGH-T219S	Samsung
SGH-T229	Samsung
SGH-T239	Samsung
SGH-T309	Samsung
SGH-T329	Samsung
SGH-T336	Samsung
SGH-T339	Samsung
SGH-T349	Samsung
SGH-T419	Samsung
SGH-T429	Samsung
SGH-T439	Samsung
SGH-T456	Samsung
SGH-T459	Samsung
SGH-T469	Samsung
SGH-T509	Samsung
SGH-T519	Samsung
SGH-T539	Samsung
SGH-T559	Samsung
SGH-T609	Samsung
SGH-T629	Samsung
SGH-T639	Samsung
SGH-T659	Samsung
SGH-T729	Samsung
SGH-T739	Samsung
SGH-T746	Samsung
SGH-T749	Samsung
SGH-T809	Samsung
SGH-T819	Samsung
SGH-T919	Samsung
SGH-T929	Samsung
SGH-U100	Samsung
SGH-U300	Samsung
SGH-U600	Samsung
SGH-U608	Samsung
SGH-U700	Samsung
SGH-U700V	Samsung
SGH-U708	Samsung
SGH-U800	Samsung
SGH-U808	Samsung
SGH-U900	Samsung

SGH-U908	Samsung
SGH-V200	Samsung
SGH-V820L	Samsung
SGH-X100	Samsung
SGH-X105	Samsung
SGH-X140	Samsung
SGH-X160	Samsung
SGH-X200	Samsung
SGH-X210	Samsung
SGH-X300	Samsung
SGH-X430	Samsung
SGH-X450	Samsung
SGH-X458	Samsung
SGH-X460	Samsung
SGH-X475	Samsung
SGH-X480	Samsung
SGH-X481	Samsung
SGH-X486	Samsung
SGH-X490	Samsung
SGH-X495	Samsung
SGH-X496	Samsung
SGH-X497	Samsung
SGH-X500	Samsung
SGH-X506	Samsung
SGH-X507	Samsung
SGH-X510	Samsung
SGH-X510V	Samsung
SGH-X520	Samsung
SGH-X526	Samsung
SGH-X530	Samsung
SGH-X540	Samsung
SGH-X550	Samsung
SGH-X566	Samsung
SGH-X576	Samsung
SGH-X600	Samsung
SGH-X610	Samsung
SGH-X620	Samsung
SGH-X630	Samsung
SGH-X636	Samsung
SGH-X640	Samsung
SGH-X650	Samsung
SGH-X660	Samsung
SGH-X660V	Samsung
SGH-X670	Samsung
SGH-X680	Samsung
SGH-X686	Samsung
SGH-X700	Samsung
SGH-X708	Samsung
SGH-X800	Samsung
SGH-X810	Samsung
SGH-X820	Samsung
SGH-X828	Samsung

SGH-X830	Samsung
SGH-X836	Samsung
SGH-Z100	Samsung
SGH-Z105	Samsung
SGH-Z107	Samsung
SGH-Z130	Samsung
SGH-Z140	Samsung
SGH-Z150	Samsung
SGH-Z170	Samsung
SGH-Z220	Samsung
SGH-Z230	Samsung
SGH-Z240	Samsung
SGH-Z300	Samsung
SGH-Z310	Samsung
SGH-Z320i	Samsung
SGH-Z360	Samsung
SGH-Z370	Samsung
SGH-Z400	Samsung
SGH-Z500	Samsung
SGH-Z510	Samsung
SGH-Z520	Samsung
SGH-Z540	Samsung
SGH-Z548	Samsung
SGH-Z560	Samsung
SGH-Z620	Samsung
SGH-Z630	Samsung
SGH-Z710	Samsung
SGH-Z720	Samsung
SGH-Z720M	Samsung
SGH-ZM60	Samsung
SGH-ZV10	Samsung
SGH-ZV30	Samsung
SGH-ZV40	Samsung
SGH-ZV50	Samsung
SGH-ZV60	Samsung
SH905i	Samsung
SoftBank 709SC	Samsung
SPH-A523	Samsung
SPH-A580	Samsung
SPH-A640	Samsung
SPH-A660	Samsung
SPH-A680	Samsung
SPH-A720	Samsung
SPH-A740	Samsung
SPH-A800	Samsung
SPH-A860	Samsung
SPH-A900	Samsung
SPH-A920	Samsung
SPH-i325	Samsung
SPH-i350	Samsung
SPH-IP830W	Samsung
SPH-M210	Samsung

SPH-M220	Samsung
SPH-M230	Samsung
SPH-M300	Samsung
SPH-M310	Samsung
SPH-M320	Samsung
SPH-M330	Samsung
SPH-M340	Samsung
SPH-M500	Samsung
SPH-M510	Samsung
SPH-M520	Samsung
SPH-M530	Samsung
SPH-M540	Samsung
SPH-M550	Samsung
SPH-M560	Samsung
SPH-M610	Samsung
SPH-M620	Samsung
SPH-M630	Samsung
SPH-M800	Samsung
SPH-M810	Samsung
SPH-M8400	Samsung
SPH-M850	Samsung
SPH-M900	Samsung
SPH-R540	Samsung
MM-8300	Sanyo
MM7500	Sanyo
PL6650	Sanyo
S750	Sanyo
SCP-2300	Sanyo
SCP-2500	Sanyo
SCP-2500NZ	Sanyo
SCP-2700	Sanyo
SCP-3100	Sanyo
SCP-3800	Sanyo
SCP-3810	Sanyo
SCP-4920	Sanyo
SCP-6600	Sanyo
SCP-6650	Sanyo
SCP-6750	Sanyo
SCP-7050	Sanyo
SCP-7300	Sanyo
SCP-8100	Sanyo
SCP-8300	Sanyo
SCP-8500	Sanyo
SCP-PRO200	Sanyo
SCP-PRO700	Sanyo
SCP2400CA	Sanyo
SCP3800CA	Sanyo
SCP6600	Sanyo
SCP6760	Sanyo
SCP7000	Sanyo
SCP7500	Sanyo
Sprint SCP-6760	Sanyo

M550	Sendo
M570	Sendo
S330	Sendo
S360	Sendo
S600	Sendo
Sendo X	Sendo
SV663	Sendo
SG-4500	Sewon
550SH	Sharp
802SH	Sharp
811SH	Sharp
812SH	Sharp
814SH	Sharp
815SH	Sharp
816SH	Sharp
820SH	Sharp
821SH	Sharp
830SH	Sharp
831SHs	Sharp
902SH	Sharp
910SH	Sharp
912SH	Sharp
913SH	Sharp
921SH	Sharp
923SH	Sharp
930SH	Sharp
931SH	Sharp
932SH	Sharp
934SH	Sharp
940SH	Sharp
DM001SH	Sharp
GX10	Sharp
GX12	Sharp
GX17	Sharp
GX20	Sharp
GX25	Sharp
GX29	Sharp
Ocean	Sharp
SL-C3100	Sharp
SoftBank 823SH	Sharp
SoftBank 824SH	Sharp
SoftBank 825SH	Sharp
SoftBank 832SH	Sharp
SoftBank 911SH	Sharp
SoftBank 920SH	Sharp
SoftBank 936SH	Sharp
SoftBank DM002SH	Sharp
Sparrow	Sharp
TM-150	Sharp
TQ-GX15	Sharp
TQ-GX30	Sharp
TQ-GX33	Sharp

TQ-GZ100	Sharp
TQ-GZ200	Sharp
TQ-V750	Sharp
V703SH	Sharp
V804SH	Sharp
v903SH	Sharp
V905SH	Sharp
Vodafone 880SH	Sharp
Vodafone V705SH	Sharp
WS011SH	Sharp
WS020SH	Sharp
A31	Siemens
A31a	Siemens
A60	Siemens
A62	Siemens
A65	Siemens
A75	Siemens
AF51	Siemens
AL21	Siemens
AX72	Siemens
AX75	Siemens
C110	Siemens
C55	Siemens
C60	Siemens
C62	Siemens
C65	Siemens
C72	Siemens
C75	Siemens
C81	Siemens
CF62	Siemens
CF75	Siemens
CF76	Siemens
CFX65	Siemens
CL75	Siemens
CX65	Siemens
CX6V	Siemens
CX70	Siemens
CX75	Siemens
CX7V	Siemens
E71	Siemens
EF81	Siemens
EL71	Siemens
ELF1	Siemens
M55	Siemens
M65	Siemens
M6V	Siemens
M75	Siemens
MC60	Siemens
ME75	Siemens
S45	Siemens
S55	Siemens
S65	Siemens

S65-Vodafone	Siemens
S68	Siemens
S6C	Siemens
S75	Siemens
SF65	Siemens
SFG75	Siemens
SHG001	Siemens
SIE-AP75	Siemens
SK65	Siemens
SK6R	Siemens
SL55	Siemens
SL5E	Siemens
SL65	Siemens
SL6C	Siemens
SL75	Siemens
SL7F	Siemens
SP65	Siemens
ST55	Siemens
SX1	Siemens
SX66	Siemens
SXG75	Siemens
Atom	Sony
CLIE PEG-VZ90	Sony
cmd	Sony
NWZ-X1000	Sony
PEG-NX73V	Sony
PEG-TJ37	Sony
PEG-UX50	Sony
PSP	Sony
TX	Sony
290i	SonyEricsson
A120a	SonyEricsson
A195i	SonyEricsson
A400i	SonyEricsson
C510	SonyEricsson
C702	SonyEricsson
C901	SonyEricsson
C902	SonyEricsson
C903	SonyEricsson
C905	SonyEricsson
D750i	SonyEricsson
E530	SonyEricsson
F100i	SonyEricsson
F305	SonyEricsson
F500i	SonyEricsson
G502	SonyEricsson
G700	SonyEricsson
G705	SonyEricsson
G705u	SonyEricsson
G900	SonyEricsson
Generic A1	SonyEricsson
J105a	SonyEricsson

J105i	SonyEricsson
J10i2	SonyEricsson
J200	SonyEricsson
J210	SonyEricsson
J220i	SonyEricsson
J230i	SonyEricsson
J300a	SonyEricsson
J300c	SonyEricsson
J300i	SonyEricsson
K200i	SonyEricsson
K220i	SonyEricsson
K300	SonyEricsson
K300i	SonyEricsson
K310a	SonyEricsson
K310c	SonyEricsson
K310i	SonyEricsson
K320i	SonyEricsson
K330	SonyEricsson
K500 Series	SonyEricsson
K500i	SonyEricsson
K508c	SonyEricsson
K508i	SonyEricsson
K510a	SonyEricsson
K510i	SonyEricsson
K530i	SonyEricsson
K550c	SonyEricsson
K550i	SonyEricsson
K550imode	SonyEricsson
K600c	SonyEricsson
K600i	SonyEricsson
K608i	SonyEricsson
K610a	SonyEricsson
K610i	SonyEricsson
K610im	SonyEricsson
K618i	SonyEricsson
K630i	SonyEricsson
K660i	SonyEricsson
K700	SonyEricsson
K700i	SonyEricsson
K750c	SonyEricsson
K750i	SonyEricsson
K770i	SonyEricsson
K790a	SonyEricsson
K790c	SonyEricsson
K790i	SonyEricsson
K800a	SonyEricsson
K800c	SonyEricsson
K800i	SonyEricsson
K810i	SonyEricsson
K850i	SonyEricsson
K858c	SonyEricsson
M600i	SonyEricsson

P100	SonyEricsson
P1i	SonyEricsson
P700i	SonyEricsson
P800	SonyEricsson
P900	SonyEricsson
P910	SonyEricsson
P910i	SonyEricsson
P990i	SonyEricsson
R306	SonyEricsson
R600	SonyEricsson
S302	SonyEricsson
S312	SonyEricsson
S500c	SonyEricsson
S500i	SonyEricsson
S700i	SonyEricsson
S710a	SonyEricsson
Satio	SonyEricsson
SO-01B	SonyEricsson
T122i	SonyEricsson
T200	SonyEricsson
T230	SonyEricsson
T238	SonyEricsson
T250a	SonyEricsson
T250i	SonyEricsson
T280i	SonyEricsson
T290a	SonyEricsson
T290i	SonyEricsson
T300	SonyEricsson
T303	SonyEricsson
T310	SonyEricsson
T312	SonyEricsson
T316	SonyEricsson
T39	SonyEricsson
T610	SonyEricsson
T616	SonyEricsson
T618	SonyEricsson
T628	SonyEricsson
T630	SonyEricsson
T637	SonyEricsson
T65	SonyEricsson
T650	SonyEricsson
T650i	SonyEricsson
T658c	SonyEricsson
T68	SonyEricsson
T700	SonyEricsson
T707	SonyEricsson
T715	SonyEricsson
TM506	SonyEricsson
TM71	SonyEricsson
U100i	SonyEricsson
U10i	SonyEricsson
U1a	SonyEricsson

U20i	SonyEricsson
U5i	SonyEricsson
U8i	SonyEricsson
V600i	SonyEricsson
V630i	SonyEricsson
V640i	SonyEricsson
V800	SonyEricsson
V802	SonyEricsson
W200a	SonyEricsson
W200c	SonyEricsson
W200i	SonyEricsson
W205	SonyEricsson
W300c	SonyEricsson
W300i	SonyEricsson
W302	SonyEricsson
W350a	SonyEricsson
W350c	SonyEricsson
W350i	SonyEricsson
W380a	SonyEricsson
W380i	SonyEricsson
W395	SonyEricsson
W508	SonyEricsson
W518a	SonyEricsson
W550c	SonyEricsson
W550i	SonyEricsson
W580	SonyEricsson
W580i	SonyEricsson
W580im	SonyEricsson
W581i	SonyEricsson
W595	SonyEricsson
W595s	SonyEricsson
W600c	SonyEricsson
W600i	SonyEricsson
W610i	SonyEricsson
W660i	SonyEricsson
W700c	SonyEricsson
W700i	SonyEricsson
W705	SonyEricsson
W705u	SonyEricsson
W710i	SonyEricsson
W715	SonyEricsson
W760a	SonyEricsson
W760c	SonyEricsson
W760i	SonyEricsson
W800c	SonyEricsson
W800i	SonyEricsson
W810c	SonyEricsson
W810i	SonyEricsson
W830a	SonyEricsson
W830c	SonyEricsson
W830i	SonyEricsson
W850i	SonyEricsson

W880i	SonyEricsson
W888c	SonyEricsson
W890i	SonyEricsson
W900i	SonyEricsson
W902	SonyEricsson
W908c	SonyEricsson
W910i	SonyEricsson
W950i	SonyEricsson
W960i	SonyEricsson
W980	SonyEricsson
W995	SonyEricsson
X2	SonyEricsson
Xperia X1	SonyEricsson
Xperia X10	SonyEricsson
Z1010	SonyEricsson
Z200	SonyEricsson
Z250i	SonyEricsson
Z300a	SonyEricsson
Z300i	SonyEricsson
Z310a	SonyEricsson
Z310i	SonyEricsson
Z320i	SonyEricsson
Z500a	SonyEricsson
Z500i	SonyEricsson
Z520a	SonyEricsson
Z520c	SonyEricsson
Z520i	SonyEricsson
Z525	SonyEricsson
Z530c	SonyEricsson
Z530i	SonyEricsson
Z550a	SonyEricsson
Z550i	SonyEricsson
Z555i	SonyEricsson
Z558i	SonyEricsson
Z600	SonyEricsson
Z610c	SonyEricsson
Z610i	SonyEricsson
Z650i	SonyEricsson
Z700i	SonyEricsson
Z710i	SonyEricsson
Z750a	SonyEricsson
Z750i	SonyEricsson
Z770i	SonyEricsson
Z780i	SonyEricsson
Z800	SonyEricsson
M5252	Spice
S580	Spice
S590	Spice
S707	Spice
S710	Spice
X1	Spice
C200	SPV

C500	SPV
C600	SPV
C700	SPV
	768 TCL
A288	TCL
D628	TCL
e300	TCL
E787	TCL
F01	TCL
F06	TCL
M218	TCL
M318	TCL
M320	TCL
M328	TCL
M580	TCL
M588	TCL
M780	TCL
M788	TCL
T106	TCL
U206	TCL
V450	TCL
Moffett	Techfaith
GU1100	Telit
A615	Tianyu
	803 Toshiba
	808 Toshiba
811T	Toshiba
813T	Toshiba
814T	Toshiba
822T	Toshiba
911T	Toshiba
G500	Toshiba
G710	Toshiba
G810	Toshiba
G900	Toshiba
G910	Toshiba
SoftBank 815T	Toshiba
SoftBank 921T	Toshiba
TG01	Toshiba
TS 921	Toshiba
TS10	Toshiba
TS21i	Toshiba
TS222i	Toshiba
TS605	Toshiba
TS608	Toshiba
TS705	Toshiba
vodafone 803T	Toshiba
vodafone 904T	Toshiba
WX320T	Toshiba
TP017	TSD
U-800	Ubiquam
PU2	Uniscope

1450M	UTStarcom
	7075 UTStarcom
Audiovox CDM-8615	UTStarcom
Audiovox CDM-8910	UTStarcom
AUDIOVOX-CDM-8930	UTStarcom
CDM-7126	UTStarcom
CDM-8074VM	UTStarcom
CDM-8932	UTStarcom
CDM-8955	UTStarcom
CDM-8960	UTStarcom
CDM7026	UTStarcom
CDM7076	UTStarcom
GPFM1238	UTStarcom
GPRS 1328	UTStarcom
GPRS1219	UTStarcom
GTX75	UTStarcom
GzOne c711	UTStarcom
PCS-1450VM	UTStarcom
SMT5800	UTStarcom
TXT8010	UTStarcom
TXT8030	UTStarcom
XV6175	UTStarcom
XV6800	UTStarcom
VT820	Vacom
V308	Vigor
TSM-100	Vitelcom
VK1500	VK Mobile
VK200	VK Mobile
VK2020	VK Mobile
VK3100	VK Mobile
VK4000	VK Mobile
VK4500	VK Mobile
VK520	VK Mobile
VK700	VK Mobile
W3319	WellcoM
W839+	WellcoM
S1	Wonu
S3	Wonu
Z-580	Zikom
ZT8988	ZTC
A211	ZTE
A261	ZTE
A37	ZTE
A861	ZTE
Bluebelt	ZTE
C70	ZTE
C77	ZTE
C78	ZTE
C79	ZTE
C88	ZTE
CORAL 400	ZTE
e810	ZTE

E811	ZTE
F102	ZTE
F105	ZTE
F150	ZTE
F152	ZTE
F153	ZTE
F156	ZTE
F158	ZTE
F159	ZTE
F165	ZTE
F188	ZTE
F232	ZTE
F252	ZTE
F256	ZTE
F260	ZTE
F850	ZTE
F852	ZTE
F858	ZTE
F866	ZTE
F912	ZTE
G i766	ZTE
G X760	ZTE
G X761	ZTE
G X960	ZTE
G-X760	ZTE
GD180	ZTE
Indie	ZTE
MD301	ZTE
MTV 4.0	ZTE
N281	ZTE
N7010	ZTE
R100	ZTE
R220	ZTE
R6	ZTE
R7	ZTE
R830	ZTE
R90	ZTE
Silverbelt	ZTE
T6	ZTE
Vodafone 1231	ZTE
W SFR552	ZTE
X760	ZTE
X990	ZTE
ZTE-A139	ZTE